



TW55000 BRAKE FLUID EXCHANGE TOOL JOB AID

Technical Service: 833-364-5932

Safety Recommendations:

- Safety glasses and gloves should be worn during the service.
- Never raise the vehicle when it is occupied.
- Always inspect braking system for leaks prior to service.
- Road test the vehicle to test the braking system.



Performing the Brake Fluid Exchange Service:

- Start with air line disconnected ensuring tool is depressurized before removing cap.
- Add appropriate Wynn's DOT rated fluid for each vehicle.
- Connect a filtered air source only. Drain filter if required.
- Install appropriate brake adapter to brake master cylinder reservoir.
- Connect service hose to brake adapter.
- Set service pressure between 15 & 20 PSI for normal service.
- Higher pressures may damage brake master cylinder reservoir.
- Open ball valve at end of service hose and check for leaks.
- Refer to manufacturers recommended brake bleed sequence.
- Test brakes when complete....before moving vehicle.

NOTE: *For Hybrid Vehicles refer to O.E.M. pressure recommendation before performing brake fluid exchange service.*

